



Industrial Automation Headquarters

Delta Electronics, Inc.

Taoyuan Technology Center
No.18, Xinglong Rd., Taoyuan City,
Taoyuan County 33068, Taiwan
TEL: 886-3-362-6301 / FAX: 886-3-371-6301

Asia

Delta Electronics (Jiangsu) Ltd.

Wujiang Plant 3
1688 Jiangxing East Road,
Wujiang Economic Development Zone
Wujiang City, Jiang Su Province, P.R.C. 215200
TEL: 86-512-6340-3008 / FAX: 86-769-6340-7290

Delta Greentech (China) Co., Ltd.

238 Min-Xia Road, Pudong District,
ShangHai, P.R.C. 201209
TEL: 86-21-58635678 / FAX: 86-21-58630003

Delta Electronics (Japan), Inc.

Tokyo Office
2-1-14 Minato-ku Shibadaimon,
Tokyo 105-0012, Japan
TEL: 81-3-5733-1111 / FAX: 81-3-5733-1211

Delta Electronics (Korea), Inc.

1511, Byucksan Digital Valley 6-cha, Gasan-dong,
Geumcheon-gu, Seoul, Korea, 153-704
TEL: 82-2-515-5303 / FAX: 82-2-515-5302

Delta Electronics Int'l (S) Pte Ltd.

4 Kaki Bukit Ave 1, #05-05, Singapore 417939
TEL: 65-6747-5155 / FAX: 65-6744-9228

Delta Electronics (India) Pvt. Ltd.

Plot No 43 Sector 35, HSIIDC
Gurgaon, PIN 122001, Haryana, India
TEL : 91-124-4874900 / FAX : 91-124-4874945

Americas

Delta Products Corporation (USA)

Raleigh Office
P.O. Box 12173, 5101 Davis Drive,
Research Triangle Park, NC 27709, U.S.A.
TEL: 1-919-767-3800 / FAX: 1-919-767-8080

Delta Greentech (Brasil) S.A.

Sao Paulo Office
Rua Itapeva, 26 - 3° andar Edificio Itapeva One-Bela Vista
01332-000-São Paulo-SP-Brazil
TEL: 55 11 3568-3855 / FAX: 55 11 3568-3865

Europe

Deltronics (The Netherlands) B.V.

Eindhoven Office
De Witbogt 15, 5652 AG Eindhoven, The Netherlands
TEL: 31-40-2592850 / FAX: 31-40-2592851

AH-4949120-01

*We reserve the right to change the information in this manual without prior notice.

2013-10-15



Delta OPC User Manual

www.deltaww.com

www.importsnab24.ru



Delta OPC User Manual

Contents

Chapter 1 Introduction

1.1	Introduction of Delta OPC and System Requirements	1-3
1.1.1	Characteristics	1-3
1.1.2	System Requirements	1-3
1.2	Installing Delta OPC	1-3
1.2.1	Installing OPC Core Components	1-3
1.2.2	Installing the Main Program of Delta OPC.....	1-4
1.2.3	Uninstalling Delta OPC.....	1-7
1.3	Usage and Introduction of Delta OPC Hard Key	1-7
1.3.1	Introduction of Hard Key.....	1-7
1.3.2	Usage of Hard Key	1-7

Chapter 2 Basic Description of Delta OPC

2.1	Basic Concept	2-2
2.1.1	First Step toward Delta OPC	2-2
2.2	Guide to Starting Delta OPC and Introduction of the Environment in Delta OPC.....	2-2
2.2.1	Starting Delta OPC	2-2
2.2.2	Description of a Configurator Screen	2-5
2.2.3	Window Title and Status Bar	2-6
2.2.4	Menu bar and Toolbar	2-7
2.2.5	Project Management Area and Working Area.....	2-8
2.2.6	Display Area of Monitor View.....	2-9

Chapter 3 Using Delta OPC

3.1	Basic Setting	3-2
3.1.1	Steps	3-2
3.1.2	Manipulating a Config File	3-2
3.1.3	Setting a Port	3-3
3.1.4	Setting a Device	3-5
3.1.5	Setting a Data Item.....	3-7
3.1.6	Starting Monitor View	3-9
3.2	Other Basic Manipulations.....	3-10
3.2.1	Edit Menu and View Menu	3-10

3.2.2 Other Related Manipulations..... 3-11

Chapter 4 Advanced Functions of Delta OPC

4.1 Advanced Setting and Connection Test 4-2

4.1.1 Conversion..... 4-2

4.1.2 Simulation 4-4

4.1.3 Alarm 4-7

4.1.4 Testing the Connection of an OPC Client..... 4-10

Chapter 1 Introduction

Contents

1.1	Introduction of Delta OPC and System Requirements	1-3
1.1.1	Characteristics	1-3
1.1.2	System Requirements	1-3
1.2	Installing Delta OPC	1-3
1.2.1	Installing OPC Core Components	1-3
1.2.2	Installing the Main Program of Delta OPC.....	1-4
1.2.3	Uninstalling Delta OPC.....	1-7
1.3	Usage and Introduction of Delta OPC Hard Key	1-7
1.3.1	Introduction of Hard Key.....	1-7
1.3.2	Usage of Hard Key	1-7

Note

Graphic representations



: Clicking the left mouse button



: Clicking the right mouse button



: Double-clicking the left mouse button




: Pressing and holding the left mouse button, and then moving the mouse without releasing the button



: Typing with a keyboard



: Operating sequence (The graphic representation is used when an operating sequence is mentioned. For example,  and .)



: Number used with a picture



: Point for attention (The item mentioned may be related to damage to equipment, property, or a human body.)

Trademark declaration

- The products and trademarks which do not belong to Delta Electronics, Inc. belong to the companies which produce and declare them.

1.1 Introduction of Delta OPC and System Requirements

Delta OPC is a Delta communication tool. SCADA and OPC clients can communicate with and monitor Delta products by means of Delta OPC. Besides, users can set communication and devices which they want to monitor by means of OPC configurators.

1.1.1 Characteristics

- Most SCADA software and OPC client software on the market is supported, e.g. iFIX and Matrikon OPC Explorer.
- Simple user interface and complete functions
- Conversions: The states or values that an OPC server receives from a PLC can be converted or processed. For example, the square root of a value can be calculated.
- Simulation: Users can set the signal function generated by a PC to simulate the state of a register or the value in a register in a PLC. For example, they can set a wave. Alternatively, the users can set a particular value or state to execute simulation.
- Monitor View: It is a simple quick client. When users do not use SCADA, they can use Monitor View to test a connection, and check whether setting is correct.
- Files whose formats are different can be imported/exported. Users can copy a large quantity of data conveniently.

1.1.2 System Requirements

Before using Delta OPC, users have to make sure that an operating system meets the requirements below.

Table 1-1 System requirement table

Item	System requirement
Operating system	Windows XP/7/8 (32/64 bits)
CPU	Pentium 1.5 G or above
Memory	256 MB or above (A memory having a capacity of 512 MB or above is recommended.)
Hard disk drive	Capacity : 500 MB or above
CD-ROM drive	For installing software (It is optionally required.)
Monitor	Resolution: 800×600; 16-bit color quality or above
Keyboard/Mouse	A general keyboard/mouse, or devices compatible with Windows
USB port	For testing Hard Key (It is obligatorily required.)
Models and connection modes supported	(1) Ethernet: AH series (2) Serial port: AH series

*. Delta OPC can be connected to multiple clients. Before users connect a client to Delta OPC, they have to make sure of the communication port with which the model used is equipped, and the connection mode supported by the model used.

1.2 Installing Delta OPC

Users have to install OPC Core Components before they install Delta OPC. Delta OPC can run normally only after OPC Core Components and Delta OPC are installed.

1.2.1 Installing OPC Core Components

OPC Core Components is software provided by the OPC authorities. First, users need to visit the OPC Foundation official website (<https://www.opcfoundation.org/Login.aspx?PageState=2>), and create an account. Then, they need to download OPC Core Components from the website <http://www.opcfoundation.org/Downloads.aspx?CI=280>. If a 32-bit operating system is used, they have to download OPC Core Components 3.00 Redistributable (x86). If a 64-bit operating system is

1

used, they have to download OPC Core Components 3.00 Redistributable (x64). After OPC Core Components is downloaded, the users have to follow instructions, and complete the installation of OPC Core Components.

1.2.2 Installing the Main Program of Delta OPC

- (1) Users can download the latest Delta OPC from the Delta official website (<http://www.deltaww.com/>). Delta OPC can be installed only after it is decompressed. The contents of the folder which is decompressed are as shown in figure 1-1. If an old version of Delta OPC has been installed on a computer, the users have to uninstall it before installing a new version of Delta OPC. (Please refer to section 1.2.3 for more information about uninstalling Delta OPC.) After the users double-click Delta OPC Setup.exe, Delta OPC will be installed.




Figure 1-1 Installing Delta OPC

- (2) Click **Next** in the installation window appears, as shown in figure 1-2.




Figure 1-2 Installation window

- (3) Read the license terms in the license agreement window. If the users agree to the terms, they have to select the **I accept the terms of the License Agreement** option button, and click **Next**, as shown in figure 1-3. If the users do not agree to the terms, they have to click **Cancel**.




Figure 1-3 License agreement

- (4) After the users select a folder in which Delta OPC will be installed, or accept the default installation path, they have to click **Install**, as shown in figure 1-4. The process of installing Delta OPC is as shown in figure 1-5.




Figure 1-4 Installation path




Figure 1-5 Process of installing Delta OPC

(5) Finally, click **Finish** to complete the installation of Delta OPC, as shown in figure 1-6.




Figure 1-6 Completing the installation of Delta OPC

After Delta OPC is installed, the short cuts to it will be automatically created on the desktop and the Start menu (**Start\Programs\Delta Industrial Automation\Delta OPC**).

1.2.3 Uninstalling Delta OPC

(1) There are two methods of uninstalling Delta OPC.

- Method 1: Open the **Control Panel** window, and click **Add or Remove Programs**. In the **Currently installed programs** box, click Delta OPC vx.xx, and then click **Remove**. x.xx denotes the version of Delta OPC, as shown in figure 1-7.




Figure 1-7 Uninstalling Delta OPC

- Method 2: Click **Uninstall** below the **Delta OPC** menu on the **Start** menu. (Default position: **Start>Programs>Delta Industrial Automation>Delta OPC>Uninstall**)
- (2) After users click **Yes**, Delta OPC will be uninstalled.

1.3 Usage and Introduction of Delta OPC Hard Key

1.3.1 Introduction of Hard Key

The main purpose of Hard Key is to drive Delta OPC so that Delta OPC can be connected to a PLC and monitor the PLC. The appearance of Hard Key is as shown in figure 1-8.



Figure 1-8 Appearance of Hard Key (for reference only)

1.3.2 Usage of Hard Key

Users can try out a connection for 30 minutes without using Hard Key. After a connection is tried out for 30 minutes, the monitoring software connected to Delta OPC (e.g. SCADA software or Monitor View provided by a Delta OPC server) can not correctly communicate with and monitor Delta products by means of Delta OPC, and a cross will be put on the icon representing a configurator on the system tray. If Hard Key is inserted into a USB port, the communication and monitoring will return to normal. As a result, in order to monitor products continuously, users need to insert Hard Key into a USB port on a computer. (Note: If Hard Key is inserted into a USB port on a computer for the first time, the computer may show that a new device is detected, but Hard Key still can not be

1

used. To install Hard Key on the computer correctly, users need to remove Hard Key, and insert it again.)

Figure 1-9 shows icons representing incorrect connections on a system tray. The left icon represents an RS-232 connection, and the right icon represents an Ethernet connection.



Figure 1-9 Icons representing incorrect connections

Chapter 2 Basic Description of Delta OPC



Contents

2.1	Basic Concept	2-2
2.1.1	First Step toward Delta OPC	2-2
2.2	Guide to Starting Delta OPC and Introduction of the Environment in Delta OPC.....	2-2
2.2.1	Starting Delta OPC	2-2
2.2.2	Description of a Configurator Screen	2-5
2.2.3	Window Title and Status Bar	2-6
2.2.4	Menu bar and Toolbar	2-7
2.2.5	Project Management Area and Working Area.....	2-8
2.2.6	Display Area of Monitor View.....	2-9

2.1 Basic Concept

2.1.1 First Step toward Delta OPC

Delta OPC provides configurators and an OPC server for users so that the users can conveniently set and connect a device (e.g. a PLC). Users write a setting into a config file (an .mdb file) by means of a configurator in an OPC server. Client software gets the names of the data items (corresponding to registers in a device) in the config file by means of the OPC server, and then sends a request to the OPC server for accessing the data in registers in a device which corresponds to the names of the data items in the config file. The OPC server sends a request by means of the communication format set by the configurator and a communication port to the device for accessing data. As shown in figure 2-1, after the users go through the process, they can read the data sent to the client software.




Figure 2-1 Framework

2.2 Guide to Starting Delta OPC and Introduction of the Environment in Delta OPC

2.2.1 Starting Delta OPC

After Delta OPC is installed successfully, the shortcuts to Delta OPC - SerialPort Configurator and Delta OPC - Ethernet Configurator will be automatically created on the desktop and the **Start** menu. If users want to connect a device by means of a serial port, they have to use Delta OPC - SerialPort Configurator. If the users want to connect a device by means of Ethernet, they have to use Delta OPC - Ethernet Configurator. After the users click a Delta OPC configurator, it will be started, as shown in figure 2-2. No matter what configurator the users start, the initial screen which appears is as shown in figure 2-3. There are only some basic functions available in a configurator window.




Figure 2-2 Starting a configurator





Figure 2-3 Initial screen

After the users click **New** on the **File** menu or  on the toolbar, a config file will be created, as shown in figure 2-4.




Figure 2-4 Creating a new config file

The users have to type a file name, select a path, and click **Save** in the **Save New MS Access Database** window, as shown in figure 2-5.




Figure 2-5 Path denoting the config file created

After a config file is created, the functions related to the configurator will be available, as shown in figure 2-6.






Figure 2-6 Configurator screen

If the users click  in the upper right corner of the configurator window which appears, the configurator window will be minimized, and the icon representing the configurator will be displayed on the system tray. If the users want to close the configurator window, they can click  in the upper right corner of the configurator window, or **Exit** on the **File** menu.

If the users close the configurator window after they save the config file created as a new file, the dialog box which asks the users whether they want to use the new config file as a default file will appear. If the users click **Yes** in the dialog box, the new config file will be read next time the configurator is started, as shown in figure 2-7.




Figure 2-7 Changing the default config file

2.2.2 Description of a Configurator Screen

A configurator screen is composed of seven parts, as shown in figure 2-8.




Figure 2-8 Configurator screen

- ❶ Window title: It displays the name that users give to the config file which is edited, and the name of the configurator which is used.
- ❷ Menu bar: There are six menus.
- ❸ Toolbar: There are two toolbars.
- ❹ Project management area: It adopts an interface which uses a hierarchical structure.
- ❺ Working area: The boxes which can be set vary with the item clicked in the project management area.
- ❻ Status bar: It displays the information about the item clicked.
- ❼ Display area of Monitor View: When Monitor View is executed, the values read and the quality of the connection created are displayed in this area.

2.2.3 Window Title and Status Bar

A title is at the top of a configurator window. The title at the top of a configurator window varies with the config file that users open, as shown in figure 2-9.

2




Figure 2-9 Title at the top of a configurator window

A status bar is at the bottom of a configurator window, as shown in figure 2-10.




Figure 2-10 Status bar at the bottom of a configurator window

The description of the function to which the mouse used moves is displayed on the left side of the status bar in a configurator window, as shown in figure 2-11.



Figure 2-11 Status bar at the bottom of a configurator window

The number of items in the section that users click is displayed on the right side of the status bar in a configurator window, as shown in figure 2-12.




Figure 2-12 Status bar at the bottom of a configurator window

2.2.4 Menu bar and Toolbar

There are six menus in the menu bar in a configurator window, as shown in figure 2-13. The items on the menus vary with the editing work carried out and the item clicked. The items shown in grayscale can not be clicked. A brief introduction of the menu bar in a configurator window is presented here, and a more detailed introduction of the menu bar in a configurator window will be presented in the following chapters.




Figure 2-13 Menu bar

- **File:** It provides the functions needed for accessing config files, as shown in figure 2-14.




Figure 2-14 Menu bar - File

- **Edit:** It provides the functions needed for editing the config file created, as shown in figure 2-15.




Figure 2-15 Menu bar - Edit

- **View:** It provides the functions needed for viewing the information in a project, and setting the way in which a working environment is displayed, as shown in figure 2-16.




- | Go | Tools | Help |
|---------------|----------------------|------|
| Back | Ctrl+Alt+Left Arrow | |
| Forward | Ctrl+Alt+Right Arrow | |
| Up One Level | | |
| Next Item | Alt+Down Arrow | |
| Previous Item | Alt+Up Arrow | |
| Expand Item | Alt+Left Arrow | |
| Collapse Item | Alt+Right Arrow | |
| Page Up | Alt+PgUp | |
| Page Down | Alt+PgDn | |
| Home | Alt+Home | |
| End | Alt+End | |

- **Tools:** It is used to display setting options, as shown in figure 2-18.



- Help
About Application...

Users can rapidly edit a project by clicking icons in the toolbar in a configurator window. The functions provided by the toolbar in a configurator include some common functions provided by the menu bar, as shown in figure 2-20.



The contents of the project management area in a configurator window are objects related to the

setting of a config file. The project management area in a configurator window adopts an interface which uses a hierarchical structure, as shown in figure 2-21. **Address Space** is used to create the objects that users want to monitor. **Conversion** is used to create conversions. **Alarm Definition** is used create limit values. **Device Parameters** and **Templates** are not provided by Delta OPC version 1.0. Please refer to the following chapters for more information about the project management area in a configurator window.



Figure 2-21 Project management area

The boxes in the working area in a configurator window vary with the item clicked in the project management area. If the item clicked in the project management area in a configurator window has subitems, the subitems will be displayed at the top of the working area, as shown in figure 2-22. Please refer to the following chapters for more information about the working area in a configurator window.




Figure 2-22 Working area

2.2.6 Display Area of Monitor View

When Monitor View is executed, the values in the registers monitored or the states of the registers monitored, and the information about the connection created are shown in the display area of Monitor View, as shown in figure 2-23. Please refer to the following chapters for more information about the usage of Monitor View.

Item ID	Value	Timestamp	Quality	Subquality	Limit
<input checked="" type="checkbox"/> port_1.PLC_1.D0	12 (VT_R8)	08/20/13 10:17:22.798	Good	Non-specific	Not Limited

Figure 2-23 Display area of Monitor View

MEMO

2

Chapter 3 Using Delta OPC

Contents

3.1	Basic Setting	3-2
3.1.1	Steps	3-2
3.1.2	Manipulating a Config File	3-2
3.1.3	Setting a Port	3-3
3.1.4	Setting a Device	3-5
3.1.5	Setting a Data Item.....	3-7
3.1.6	Starting Monitor View	3-9
3.2	Other Basic Manipulations.....	3-10
3.2.1	Edit Menu and View Menu	3-10
3.2.2	Other Related Manipulations.....	3-12


3.1 Basic Setting

3.1.1 Steps

Users can complete the setting of target registers, and write data into a config file which is used by an OPC server by following the steps below.

- Manipulate a config file.
- Set a port. (Delta OPC - Ethernet Configurator is not equipped with the function needed for setting ports. If Delta OPC - Ethernet Configurator is used, this step can be skipped.)
- Set a device.
- Set a data item.
- Start Monitor View.

3.1.2 Manipulating a Config File

Users can not only create a new config file, but also open an old config file. After they click  on the toolbar, or **Open...** on the **File** menu, the **Open** window will appear, as shown in figure 3-1. The users can select a config file which has been created in the **Open** window.




Figure 3-1 Opening an old file

After the users click an historic item on the **File** menu, a file which was edited before will be opened, as shown in figure 3-2.




Figure 3-2 Historic item list

If the users want to save a config file with a new name or in a new path, they have to click **Save As...** on the **File** menu, and type a file name, select a path, and click **Save** in the **Save As** window. If the users want to export/import a config file, they can click **Export (WinCE, Embedded WinNT).../CSV Export/CSV Import/XML Export.../XML Export Schema.../XML Import.../XML Validate...** on the **File** menu, or **CSV Export/CSV Import** on the toolbar, as shown in figure 3-2 and figure 3-3. The functions needed for importing/exporting config files are described below.




Figure 3-3 CSV Import/CSV Export

Table 3-1 Functions needed for importing/exporting config files

Item	Description
Export (WinCE, Embedded WinNT)...	Users can export data to a .txt file which is used by an embedded system functioning as an OPC server.
CSV Export	Users can select the items which they want to export to a .csv file, and select the items which they want to import from a .csv file. When they export data, they can select an option button in the Delimiters section, and select the LF cell line breaks checkbox in the Save As window. When they import data, they can select checkboxes in the Import settings section, and select the Insert all invalid records into file checkbox in the Open window.
CSV Import	
XML Export...	Users can export a config file to an .xml file.
XML Export Schema...	A schema file in which there is no data set is exported to an .xml file so that users can edit the .xml file by means of another tool.
XML Import...	Users can import a config file saved as an .xml file.
XML Validate...	XML Validate... is used to check whether the file selected is a config file conforming to an XML format. Only the file conforms to an XML format can be imported to Delta OPC.

3.1.3 Setting a Port

If a port is set, the communication format used to connect a PLC can be set. If users want to create a port, they can click **Address Space** in the project management area, right-click it, point to **New**

on the context menu, and click **Port**, as shown in figure 3-4. The users can also click  on the toolbar, or click the **File** menu, point to **New**, and click **Port**.




Figure 3-4 Creating a new port

After a new port is created, the window appearing will be as shown in figure 3-5. The items which need to be set are described below.




Figure 3-5 Setting a port

- ❶ Users can type the name of the port created. They can type 50 characters at most. Underlines can be typed, but special marks such as *, #, ?, \, %, and @ can not be typed.
- ❷ Setting the communication format used by a computer: Users have to make sure of the communication port number used, and the communication format used by the object which is connected.

After the users complete the setting of a port, they have to click **Apply** to write the setting into the config file created. If the users click **Reset**, the previous setting saved will be restored. If the users click **Add New**, a new port will be created. Please note that Delta OPC - Ethernet Configurator is

not equipped with the function needed for setting ports. If Delta OPC - Ethernet Configurator is used, the step of setting ports can be skipped.

3.1.4 Setting a Device

If users set a device, they can set the model which they want to connect, and set a connection. The way in which a device is set in Delta OPC - SerialPort Configurator is different from the way in which a device is set in Delta OPC - Ethernet Configurator.

➤ Setting a device in Delta OPC - SerialPort Configurator

After users complete the setting described in section 3.1.3, they have to click a port in the project management area, right-click it, point to **New** on the context menu, and click **Device**, as shown in figure 3-6. The users can also click  on the context menu, or click the **Edit** menu, point to **New**, and click **Device**.




Figure 3-6 Creating a new device (Delta OPC - SerialPort Configurator)

After a new device is created, the window appearing will be as shown in figure 3-7. The items which need to be set are described below.





Figure 3-7 Setting a device (Delta OPC - SerialPort Configurator)

- ❶ Users can type the name of the device created. They can type 50 characters at most. Underlines can be typed, but special marks such as *, #, ?, \, %, and @ can not be typed. The first character can not be a numeral. The station address that the users can type is the station address of a communication port on the model which the users want to connect.
- ❷ Users have to select a model. Only AH500 series PLCs are supported for the time being.

- ③ Users have to set a communication format. They can set timeouts, the number of times the reading/writing of data is retried, and a time interval. (A millisecond is a unit.) In the Optimizations section, the users can set the maximum quantity of data which can be read/written at a time.

After the users complete the setting of a device, they have to click **Apply** to write the setting into the config file created. If the users click **Reset**, the previous setting saved will be restored. If the users click **Add New**, a new device will be created.

➤ **Setting a device in Delta OPC - Ethernet Configurator**

If users want to create a device, they can click **Address Space** in the project management area, right-click it, point to **New** on the context menu, and click **Device**, as shown in figure 3-8. The users can also click  on the toolbar, or click the **Edit** menu, point to **New**, and click **Device**.




Figure 3-8 Creating a new device (Delta OPC - Ethernet Configurator)

After a new device is created, the window appearing will be as shown in figure 3-9. The items which need to be set are described below.




Figure 3-9 Setting a device (Delta OPC - Ethernet Configurator)

- ① Users can type the name of the device created. They can type 50 characters at most. Underlines can be typed, but special marks such as *, #, ?, \, %, and @ can not be typed. The first character can not be a numeral. The IP address that the users can type is the IP address of the model which the users want to connect, and the TCP port that the users

can set is the TCP port of the model which they want to connect.

- ② Users have to select a model. Only AH500 series PLCs are supported for the time being.
- ③ Users have to set a communication format. They can set timeouts, the number of times the reading/writing of data is retried, and a time interval. (A millisecond is a unit.) In the Optimizations section, the users can set the maximum quantity of data which can be read/written at a time.


After the users complete the setting of a device, they have to click **Apply** to write the setting into the config file created. If the users click **Reset**, the previous setting saved will be restored. If the users click **Add New**, a new device will be created.

If the setting value in a box exceeds the limit set by the box, a warning message as shown in figure 3-10 will appear. The setting value in a box can be saved only if it does not exceed the limit set by the box.



Figure 3-10 Warning message

3.1.5 Setting a Data Item

A data item corresponds to a register in a PLC. If users want to create a data item, they have to click a device in the project management area, right-click it, and point to **New** on the context menu, and click **Data Item**, as shown in figure 3-11. The users can also click  on the context menu, or click the **Edit** menu, point to **New**, and click **Data Item**.




Figure 3-11 Creating a new data item

If the users want to manage several data items under a device in the project management area, they can click the device, right-click it, point to **New** on the context menu, click **Folder**, and move the data items to the folder created or create data items in the folder created.

After a data item is created, the window appearing will be as shown in figure 3-12. The items which need to be set are described below. After the users complete the steps above, they can access the items set by means of SCADA software as long as Delta OPC runs on the operating system.





Figure 3-12 Setting a data item

- ❶ Users can type the name of the data item created. They can type 50 characters at most. Underlines can be typed, but special marks such as *, #, ?, \, %, and @ can not be typed. The first character can not be a numeral. If the name typed is a register name, the starting address and the data type in ❷ will change by themselves. (If the name typed is a register name, it can not be different from the starting address in ❷. The users can select a data type in accordance with their needs.) The users can type any characters in the **Description** box. They can type 50 characters at most.
- ❷ Users can set the data type of the register which they want to use. If the users select the **Vector** checkbox, and set the number of elements, the number of registers which they want to use will be the number of elements they set, and the registers which they want to use will start from the starting address set. After the users select the **Use conversion** checkbox, they can select a conversion which has been created in the **Conversions** section. Please refer to section 4.1.1 for more information about **Conversions**.
- ❸ If users select the **Simulate** checkbox, they can select a simulated signal which has been created in the **Simulation Signals** section, and the value that the OPC server used gets will be the simulated signal selected, whether the OPC server used is connected to a PLC or not. The users can select a waveform in the **Signal** drop-down list box. They can also select the **Manual** checkbox. The constant in the **Value** box can be used as a simulated value. Please refer to section 4.1.2 for more information about **Simulation Signals**.
- ❹ After users select the **Generate Alarms** checkbox, they can select an alarm which has been created in the **Alarm Definitions** section. If the value in a register in a client reaches a limit value, an alarm will occur in the client. Please refer to section 4.1.3 for more information about **Alarm Definitions**.

After the users complete the setting of a data item, they have to click **Apply** to write the setting into the config file created. If the users click **Reset**, the previous setting saved will be restored. If the users click **Add New**, a new data item will be created. If the users click **Additional properties...**, they can describe the data item in the **Data Item – Additional Properties** window.

3.1.6 Starting Monitor View

Monitor View is a simple built-in SCADA tool. Monitor View can be used to check whether a connection is correct. After users complete the setting described above, and connect a device, they can start Monitor View by clicking  on the toolbar, by right-clicking the project management area, and clicking **Monitor View** on the context menu which appears, or by clicking **Monitor view** on the **View** menu, as shown in figure 3-13. After Monitor View is started, the display area of Monitor View will appear at the bottom of the window.




Figure 3-13 Monitor View

If the users click a device in the project management area after Monitor View is started, the data items which have been created for this device will be displayed in the display area of Monitor View, as shown in figure 3-14.




Figure 3-14 Display area of Monitor View

- 1 After users select a data item, the cells at the right side of the data item will display data. Please refer to table 3-2 for more information about the columns in the display area of Monitor View.

Table 3-2 Description of the display area of Monitor View

Item	Description
Item ID	It is a path pointing to a data item, and is represented by Name of a port. Name of a device. Name of a data item.
Value	Value of data item
Timestamp	Time when a connection is started
Quality	Quality of a connection
Subquality	Subquality of a connection If a connection can not be started, the reason that the connection can not be started will be displayed.
Limit	Reserved

3

If Delta OPC Hard Key is not inserted, Monitor View or SCADA software can only be connected for 30 minutes. If Monitor View or SCADA software is disconnected automatically, users can connect Monitor View or the SCADA software again by restarting Monitor view or the SCADA software. As a result, Hard Key must be inserted. Please refer to chapter 1 for more information about Hard Key.

3.2 Other Basic Manipulations

3.2.1 Edit Menu and View Menu

Users can complete basic setting by following the steps described above. Delta OPC also provides convenient interfaces. After users create items in the project management area, the subitems that an item in the project management area has will be displayed at the top of the working area if the item is clicked. As shown in figure 3-15, there are two data items displayed at the top of the working area. If users double-click an item, the page for the item will appear. The items at the top of the working area can also be edited. For example, they can be cut, copied, and pasted.




Figure 3-15 Viewing the data items created

If users want to further edit an item in the project management area or at the top of the working area, they can right-click the item, and click an item on the context menu which appears, or click an item on the Edit menu or the View menu. The context menu which will appear after an item in the project management area is right-clicked and the context menu which will appear after an item at the top of the working area is right-clicked are as shown in figure 3-16. The **Edit** menu and the **View** menu are as shown in figure 3-17. They are described in table 3-3 and table 3-4.










Figure 3-16 Context menus

Figure 3-17 **Edit** menu and **View** menuTable 3-3 Description of the **Edit** menu


Item	Description
New	Creating a new item (e.g. a port, a device, or a data item)
Rename	Renaming an item
Multiply...	Setting the names of items, the number of digits in a serial number, a starting serial number, and the number of items which will be created
Cut, Copy, Paste, Delete	Editing the item selected
Select All, Invert Selection	Selecting items

Table 3-4 **View** menu

Item	Description
Toolbars	Opening/Closing the toolbar
Status Bar	Opening/Closing the status bar at the bottom of the window
Large Icons, Small Icons, List, Details	Large Icons, Small Icons, List, and Details on the View menu can be used to switch among the ways in which the items in the working area are displayed. Alternatively,  on the toolbar can be used to switch among the ways in which the items in the working area are displayed.
Dialog view	Dialog view on the View menu can be used to open or close the pane at the bottom of the working area. Alternatively,  on the toolbar can be used to open or close the pane at the bottom of the working area.
Monitor view	Monitor view on the View menu can be used to enable/disable Monitor View. Alternatively,  on the toolbar can be used to enable/disable Monitor View.
Sort by	If Details on the View menu, or  on the toolbar is clicked, the items at the top of the working area will be organized in the order specified.
Show/hide columns	Users can set the columns which they want to display. After the Details on the View menu, or  on the toolbar is clicked, the columns that the users want to display will be displayed at the top of the working area.
Global Refresh	Writing all setting values into a config file, and then reading the setting values in the config file
Subtree Refresh	Writing the setting values of the item selected into a config file, and then reading the setting values in the config file

3.2.2 Other Related Manipulations

If users want to switch among different items or different pages, they can click an item on the **Go** menu, as shown in figure 3-18. The **Go** menu is described in table 3-5.

A screenshot of the 'Go' menu in the software. The menu is titled 'Go' and contains several options with their corresponding keyboard shortcuts. The options are: Back (Ctrl+Alt+Left Arrow), Forward (Ctrl+Alt+Right Arrow), Up One Level, Next Item (Alt+Down Arrow), Previous Item (Alt+Up Arrow), Expand Item (Alt+Left Arrow), Collapse Item (Alt+Right Arrow), Page Up (Alt+PgUp), Page Down (Alt+PgDn), Home (Alt+Home), and End (Alt+End).

Go	Tools	Help
Back	Ctrl+Alt+Left Arrow	
Forward	Ctrl+Alt+Right Arrow	
Up One Level		
Next Item	Alt+Down Arrow	
Previous Item	Alt+Up Arrow	
Expand Item	Alt+Left Arrow	
Collapse Item	Alt+Right Arrow	
Page Up	Alt+PgUp	
Page Down	Alt+PgDn	
Home	Alt+Home	
End	Alt+End	

Figure 3-18 **Go** menu

Table 3-5 Description of the **Go** menu

Item	Description
Back, Forward	Jumping to the previous page, jumping to the next page
Up One Level	Jumping to item at the upper level
Next Item, Previous Item	Jumping to the next item or the previous item in the project management area
Expand Item, Collapse Item	Expanding or collapsing the item selected
Page Up, Page Down	Jumping to the first item or the last item displayed in the window
Home, End	Jumping to the first item or the last item in the project management area

After **Options...** on the **Tools** menu is clicked, the **Options** window will appear, as shown in figure 3-19. The **Options** window is described in table 3-6.




Figure 3-19 **Options** window

Table 3-6 Description of the **Options** window

Item	Description
Automatically apply changes when selection is changed	If there are changes in a page, users do not need to click Apply , and the changes will be saved automatically.
Enable hover selection	As long as the number of milliseconds for which the mouse cursor hovers over an item reaches the number of milliseconds that users set, the item will be selected.

Item	Description
Update Rate	Users can set the frequency with which the data in the display area of Monitor View is updated.

After **About Application...** on the **Help** menu is clicked, the **About Delta OPC** window will appear, as shown in figure 3-20. The version of the software used and other information are displayed in the **About Delta OPC** window.




Figure 3-20 **About Delta OPC** window

MEMO

3

Chapter 4 Advanced Functions of Delta OPC

Contents

4.1	Advanced Setting and Connection Test	4-2
4.1.1	Conversion	4-2
4.1.2	Simulation	4-4
4.1.3	Alarm	4-7
4.1.4	Testing the Connection of an OPC Client	4-10

4.1 Advanced Setting and Connection Test

In addition to the basic setting described in chapter 3, Delta OPC provides convenient advanced tools. These advanced tools are conversions, simulations, and alarms. They are described in the following sections.

4.1.1 Conversion

If users want to adjust the values in registers in the device which they want to connect, they can set a conversion. After the setting of a conversion is complete, and the conversion is started, an OPC client will monitor the values gotten from the conversion.

If users want to create a conversion, they have to click **Conversion** in the project management area, right-click it, point to **New** on the context menu, and click **Conversion**, as shown in figure 4-1.




Figure 4-1 Creating a new conversion

After a new conversion is created, the window appearing will be as shown in figure 4-2. The items which need to be set are described below.




Figure 4-2 Setting a conversion

- ❶ Users can type the name of the conversion created. They can type 50 characters at most.
- ❷ Users can select a conversion type. If the **No (make float)** option button is selected, no conversion will be carried out. If the **Linear** option button is selected, a register value in the range of the maximum register value set to the minimum register value set will correspond to a value in the range of the maximum engineering value set to the minimum engineering value set. If the **Square root** option button is selected, the square root of a value will be calculated. In the **Conversion parameters** section, the users can set a minimum register value in the **Low IR** (instrument range) box, a maximum register value in the **High IR** (instrument range) box, a minimum engineering value in the **Low EU** (engineering unit) box, and a maximum engineering value in the **High EU** (engineering unit) box.
- ❸ If the **None** option button in the **Clamping** section is selected, there will be no maximum engineering value and no minimum engineering value. If the **Clamp on EU** option button in the **Clamping** section is selected, the value in the **Low EU** box will be a minimum engineering value, and the value in the **High EU** box will be a maximum engineering value. If the **As specified** option button is selected, the value in the **Low clamp** box will be a minimum engineering value, and the value in the **High clamp** box will be a maximum engineering value.

After the users complete the setting of a conversion, they have to click **Apply** to write the setting into the config file created. If the users click **Reset**, the previous setting saved will be restored. If the users click **Add New**, a new conversion will be created.

After the users complete the setting of conversions, they can click a data item which needs to be converted in the project management area. After the users select the **Use conversion** checkbox, they can select a conversion which has been created in the **Name** drop-down list box, as shown in figure 4-3.




Figure 4-3 Using a conversion

4.1.2 Simulation

After a simulation is created, the simulated signal set or the constant set will be used as the value in a register. After the setting of a simulation is complete, and the simulation is started, an OPC client will monitor simulated values.

If users want to create a simulation, they have to click **Simulation Signals** in the project management area, right-click it, point to **New** on the context menu, and click **Simulation Signal**, as shown in figure 4-4.




Figure 4-4 Creating a new simulation

After a new simulation is created, the window appearing will be as shown in figure 4-5. The items which need to be set are described below.




Figure 4-5 Setting a simulation

- ❶ Users can type the name of the simulation created. They can type 50 characters at most.
- ❷ The parameters which can be set in the **Parameters** section vary with the option button selected in the **Type** section. The option buttons in the **Type** section are described below.
 - **Read count:** The value read from a register automatically increases by one every time.

- Users do not need to set any parameters.
- **Write count:** The value written into a register automatically increases by one every time. Users do not need to set any parameters.
 - **Random:** Users have to set a value in the **Position** box, and a value in the **Amplitude** box. A random value in the range of the value in the **Position** box to the value in the **Position** box plus the value in the **Amplitude** box is generated.
 - **Ramp:** Users have to set a value in the **Position** box, a value in the **Amplitude** box, a value in the **Period** box, and a value in the **Phase** box. A ramp in the range of the value in the **Position** box to the value in the **Position** box plus the value in the **Amplitude** box is generated.
 - **Sine:** Users have to set a value in the **Position** box, a value in the **Amplitude** box, a value in the **Period** box, and a value in the **Phase** box. A sine wave in the range of the value in the **Position** box minus the value in the **Amplitude** box to the value in the **Position** box plus the value in the **Amplitude** box is generated.
 - **Square:** Users have to set a value in the **Position** box, a value in the **Amplitude** box, a value in the **Period** box, a value in the **Phase** box, and a value in the **Ratio** box. A square wave in the range of the value in the **Position** box to the value in the **Position** box plus the value in the **Amplitude** box is generated. The ratio of the time for which a position of the square wave generated lasts to the period of the square wave depends on the value in the **Ratio** box. In figure 4-6, the ratio of the time for which a position of the square wave lasts to the period of the square wave is 0.2.




Figure 4-6 Square wave

- **Triangle:** Users have to set a value in the **Position** box, a value in the **Amplitude** box, a value in the **Period** box, a value in the **Phase** box, and a value in the **Ratio** box. A triangle wave in the range of the value in the **Position** box to the value in the **Position** box plus the value in the **Amplitude** box is generated. The ratio of the time for which the triangle wave generated moves up to the period of the triangle wave depends on the value in the **Ratio** box. In figure 4-7, the ratio of the time for which the triangle wave moves up to the period of the triangle wave is 0.6.




Figure 4-7 Triangle wave

- **Step:** Users have to set a value in the **Position** box, a value in the **Amplitude** box, a value in the **Period** box, a value in the **Phase** box, and a value in the **# of steps** box. A step wave in the range of the value in the **Position** box to the value in the **Position** box plus the value in the **Amplitude** box is generated. If the value in the **# of steps** box is 3, the step wave generated will be as shown in figure 4-8.




Figure 4-8 Step wave

After the users complete the setting of a simulation, they have to click **Apply** to write the setting into the config file created. If the users click **Reset**, the previous setting saved will be restored. If the users click **Add New**, a new simulation will be created.

After the users complete the setting of simulations, they can click a data item which needs to be simulated in the project management area. After the users select the **Simulate** checkbox, they can select a simulation which has been created in the **Signal** drop-down list box, as shown in figure 4-9. If the users select the **Manual** checkbox, and type a value in the **Value** box, the value will be simulated.




Figure 4-9 Starting a simulation

4.1.3 Alarm

Users can set an alarm which is triggered when the value in a register reaches a limit value. After the setting of an alarm is complete, and the alarm is enabled, an OPC client which supports OPC AE can monitor the alarm if the alarm is triggered.

If users want to create an alarm, they have to click **Alarm Definitions** in the project management area, right-click it, point to **New** on the context menu, and click **Limit Alarm Definition** or **Digital Alarm definition**, as shown in figure 4-10. **Digital Alarm definition** is used to define an alarm for Boolean registers. **Limit Alarm Definition** is used to define an alarm for other register types (exclusive of string registers).




Figure 4-10 Creating a new alarm

➤ Limit Alarm Definition

After a new limit alarm is created, the window appearing will be as shown in figure 4-11. The items which need to be set are described below.




Figure 4-11 Setting an alarm

- ❶ Users can type the name of the alarm created. They can type 50 characters at most. The value in the **Update rate** box indicates the frequency with which the status of the alarm created is updated. The users can set a value in the **Deadband** box. In order to prevent an alarm from being triggered continually by the oscillations of a value around a limit value, the alarm is triggered only once when the oscillations of a value stay within a deadband.
- ❷ Users can set limit values in the **Limit alarm definition** section.
 - **Limit:** If the **Limit** checkbox for a limit value is selected, the alarm created is triggered when the value in a register reaches the limit value. Users can set four limit values. If the **Return to normal** checkbox is selected, a message is displayed when the value in a register returns to normal.
 - **Value:** Users can set limit values.
 - **Message Body:** Message displayed in a client when the value in a register reaches a limit value
 - **Severity:** Degree of severity displayed in a client when the value in a register reaches a limit value
 - **Req. Ack.:** If the alarm created is triggered, it will not be canceled until an acknowledgement is given.

After the users complete the setting of an alarm, they have to click **Apply** to write the setting into the config file created. If the users click **Reset**, the previous setting saved will be restored. If the users click **Add New**, a new alarm will be created.

➤ Digital Alarm Definition

After a new digital alarm is created, the window appearing will be as shown in figure 4-12. The items which need to be set are described below.




Figure 4-12 Setting an alarm

- ❶ Users can type the name of the alarm created. They can type 50 characters at most. The value in the **Update rate** box indicates the frequency with which the status of the alarm created is updated.
- ❷ Users can set the message which appears when the alarm created is triggered in the **Digital alarm definition** section. If the **Enable** checkbox is selected, the alarm created will be enabled.
 - **Value:** Users can set the state which triggers the alarm created. If the **Return to normal** checkbox is selected, a message is displayed when the state of a register returns to normal.
 - **Message Body:** Message displayed in a client when the state of a register is the state selected in the **Value** drop-down list box
 - **Severity:** Degree of severity displayed in a client when the state of a register is the state selected in the **Value** drop-down list box
 - **Req. Ack.:** If the alarm created is triggered, it will not be canceled until an acknowledgement is given.

After the users complete the setting of an alarm, they have to click **Apply** to write the setting into the config file created. If the users click **Reset**, the previous setting saved will be restored. If the users click **Add New**, a new alarm will be created.

After the users complete the setting of alarms, they can click a data item which needs to use an alarm in the project management area. After the users select the **Generate Alarms** checkbox, they can select an alarm which has been created in the **Limit Alarm** drop-down list box or in the **Digital Alarm** drop-down list box, as shown in figure 4-13. If a limit alarm is selected, the message typed in the **Mess. prefix** box and an alarm message set appear when the alarm is triggered. If a digital alarm is selected, the message typed in the **Mess. prefix** box and the alarm message set appear when the alarm is triggered.




Figure 4-13 Starting an alarm

4.1.4 Testing the Connection of an OPC Client

If users want to connect an OPC client to Delta OPC, they have to use the OPC client to search for the OPC servers which exist in the computer used, and select a connection. The creation of a connection between iFIX and a Delta OPC server is shown in figure 4-14. (Note: Please refer to related manuals for more information about the operation and usage of iFIX.)

In figure 4-14, iFIX finds the OPC servers which have been installed on the computer used. If users want to connect iFIX to a Delta serial OPC server, they have to select Delta.AHModbusSerialDA or Delta.AHModbusSerialDA.1. If the users want to connect iFIX to a Delta Ethernet OPC server, they have to select Delta.AHModbusEthernetDA or Delta.AHModbusEthernetDA.1.




Figure 4-14 Selecting a Delta OPC server which is running

The users have to select the registers which they want to monitor. As shown in figure 4-15, the hierarchical structure created in a Delta OPC configurator is shown in the **Path** section, and the data items created in the Delta OPC configurator are shown in the **Items** section. In figure 4-15, **Port_1.PLC_1.TAG1** indicates the port, device, and data item created in a Delta OPC configurator. After the users select data items, they can add the data items to the list which iFIX will monitor.




Figure 4-15 Selecting data items which have been created

If the monitoring function that iFIX has is executed after the users complete related setting, the data items selected will be monitored, as shown in figure 4-16.




Figure 4-16 Information about a data item monitored

MEMO

4